


Parts Reference Guide  
Guía de referencia de piezas  
Pièces Guide de référence


Schematic Drawings Inside  
Plano esquemático en el interior  
Schéma intérieur





# Low Noise Compressor

# AC32024





# Low Noise Compressor

# AC32024

## REPLACEMENT PARTS LIST • ONDERDELENLIJST • ERSATSTEILE-LISTE • LISTE DE PIÈCES DE RECHANGE

PART NO.	DESCRIPTION	OMSCHRIJVING	BESCHREIBUNG	DÉSIGNATION
01	203010.044	SCREW	SCHROEF	VIS
02	205020.011	SPRING WASHER	VEER SLUITRING	FEDER UNTERLEGSSCHEIBE
03	311111.029	CYLINDER HEAD	CILINDERKOP	ZYLINDERKOPF
04	210002.009	SEAL	AFDICHTING / ZEGEL	DICHTUNG
05	203014.001	SCREW	SCHROEF	SCHRAUBE
06	315111.006	LIMIT RANGE IMPLEMENT	BESTURINGSSELEMENT	KONTROLLEINHEIT
07	315211.005	VALVE BLOCK	KLEPPENBLOK	VENTILBLOCK
08	315311.015	VALVE BOARD	KLEPBORD	VENTILBRÜCKE
09	210002.008	O-RING	O-RING	O-RING
10	315211.005	VALVE BLOCK	KLEPPENBLOK	VENTILBLOCK
11	315511.003	VALVE PLATE CLAMP	KLEPPLAATKLEM	VENTILPLATTENKLEMMER
12	203012.005	HEX COUNTERSINK SCREW	ZESKANTSCHROEF VERZINKT	SECHSKANT SCHRAUBE
13	312111.004	PISTON CAP	ZUIGERHOUDER	KOLBENKAPPE
14	312711.006	PISTON RING	ZUIGERVEER	KOLBENRING
15	313112.020	CONNECTING ROD	VERBINDINGSSTANG	PLEUELESTANGE
16	311311.030	CYLINDER	CILINDER	ZYLINDER
17	323211.015	WIND SCOOPER	WIND VANGER	LÜFTERRAD
18	203014.005	SCREW	SCHROEF	SCHRAUBE
19	205024.003	CIRCLIP FOR SHAFT	BORGRING VOOR SCHACHT	SICHERUNGSRING
20	323112.010	B FAN	A VENTILATOR	LAGER
21	203017.004	HEX SCREW	ZESKANTSCHROEF	SECHSKANTSCHRAUBE
22	204013.002	NUT	MOER	MUTTER
23	352212.002	FOOT PAD	VOETKUSSEN	FUSSPOLSTER
24	314111.029	B CRANKCASE	B KRUKKAST	LAGER
25	208001.070	BEARING	LAGER	LAGER
26	321311.018	MOTOR ROTOR	MOTORROTOR	ROTOR
27	321111.036	MOTOR STATOR	MOTOR STATOR	STARTER
28	207002.003	STRAIGHT KEY	RECHTE SLEUTEL	SCHLÜSSEL GERADE
29	201011.017	SCREW	SCHROEF	SCHRAUBE
30	314111.028	A CRANKCASE	A KRUKKAST	LAGER
31	208001.069	BEARING	LAGER	LAGER
32	313411.016	CRANK	SLINGER / KRUK	KURBEL
33	323112.009	A FAN	B VENTILATOR	VENTILATOR A
34	203016.006	SCREW	SCHROEF	SCHRAUBE
35	324311.005	CAPACITOR COVER	CONDENSATOR DEKSEL	LAGER ABECKUNG
36	324212.016	CIRCUIT BREAKER	STROOMONDERBREKER	SCHUTZSCHALTER
37	324111.028	RUNNING CAPACITOR	LOPEDE CONDENSATOR	LAUFENDER CONDENSATOR
38	324111.027	STARTING CAPACITOR	STARTCONDENSATOR	STARTCONDENSATOR
39	331411.001	ELECTRONIC RELEASE SWITCH	ELEKTRONISCHE ONTGRENDELINGSSCHAKELAAR	ELEKTRONISCHER AUSLÖSER
40	324311.006	CAPACITOR SHELL	CONDENSATORHUIS	KONDENSATORSCHALE
41	203020.002	COMBINATION SCREW	VERBINDINGSCHROEF	KOMBINATIONSSCHRAUBE
42	326211.005	POWER CORD BUCKLE	STROOMKABELGESP	NETZKABELSCHNALLE
43	353112.006	AIR FILTER	LÜCHTFILTER	LÜFTFILTER
44	341111.010	HUSH PIPE	STILTEPIJP	ROHR
45	352113.005	HANDLE SLEEVE	HANDVATHULS	GRIFFHÜLSE
46	352111.016	HANDLE	HANDVAT	GRIFF
47	204011.003	NUT	MOER	MUTTER
48	205010.007	GASKET	PAKKING	DICHTUNG
49	201010.018	BOLT	BOUT	BOLZEN
50	211002.001	EXTENSION SPRING	VERLENGINGSVEER	AUSZUGSFEDER
51	355311.002	HAND ROD	HANDSTANG	HANDSTANGE
52	205010.003	FLAT WASHER	PLATTE SLUITRING	UNTERLEGSSCHEIBE
53	355411.003	TOOL PLATE	GEREDSCHAPPLAAT	WERKZEUGPLATTE
54	203012.003	INTERNAL HEX ROUND HEAD SCREW	INTERNE ZESKANTSCHROEF MET RONDE KOP	RUNDKOPFSCHRAUBE
55	201012.011	BOLT	BOUT	BOLZEN
56	351111.114	TANK	TANK	TANK
57	352314.001	FOOT WHEEL	VOETWIEL	RAD
58	352411.004	WHEEL SHAFT	WIELKAST	RAD WELLE
59	352213.001	FOOT PAD	VOETKUSSEN	FUSSPOLSTER
60	201012.013	BOLT	BOUT	BOLZEN
61	333611.001	BALL VALVE	KOGELKLEP	KUGELVENTIL
62	203018.001	BOLT	BOUT	BOLZEN
63	343511.005	ELBOW	BOCHT	ELLBOGEN
64	333311.027	REGULATOR	REGULATOR	REGLER
65	203017.007	SCREW	SCHROEF	SCHRAUBE
66	342111.002	QUICK COUPLING	SNELKOPPELING	REG
67	332211.018	PRESSURE GAUGE	DRUKMETER	DRUCKANZEIGE
68	341211.016	METAL PIPE	METALEN PIJP	METALLROHR
69	355211.013	INSTRUMENT PANEL	INSTRUMENTENPANEEL	INSTRUMENTENTAFEL
70	333111.005	SAFETY VALVE	VEILIGHEIDSKLEP	SICHERHEITSVENTIL
71	331112.017	PRESSURE SWITCH	DRUKSCHAKELAAR	DRUCKSCHALTER
72	342311.002	SWIVEL JOINT	ROTTERENDE / ZWENK KOPPELING	DREHGELENK
73	342312.002	SWIVEL JOINT NUT	ROTTERENDE / ZWENK KOPPELING MOER	MUTTER DREHGELENK
74	316611.001	GASKET	PAKKING	DICHTUNG
75	333511.013	CHECK VALVE	CONTROLEKLEP / TERUGSLAGKLEP	RÜCKSCHLAGVENTIL
76	343511.031	ELBOW	BOCHT	ELLBOGEN



# Low Noise Compressor

# AC32024

## REPLACEMENT PARTS LIST • LISTA DE PARTES DE REPUESTO • ERSATSTEILE-LISTE • LISTE DE PIÈCES DE RECHANGE

PART NO.	DESCRIPTION	DESCRIPCIÓN	BESCHREIBUNG	DÉSIGNATION	
77	344311.001	NUT	MOER	MUTTER	ECROU
78	341411.002	UNLOADING PIPE	SPOELBUIS / ZUIVERINGSBUIS	AUSBLASROHR	TUBE DE PURGE
79	341511.033	EXHAUST PIPE	UITLAATPIJP	AUSPUFF	TUBE DE SORTIE
80	343311.010	T-JUNCTION	T-SPLITSING	T-KREUZUNG	JONCTION EN T
81	341211.015	CONNECTING PIPE	VERBINDINGSPIJP	VERBINDUNGSROHR	TUBE DE CONNEXION
82	343511.030	ELBOW	BOCHT	ELLBOKEN	COUDE
83	334111.007	POWER CORD	STROOMKABEL	NETZKABEL	CORDON D'ALIMENTATION