



NS20BXP


Construction Stapler

Parts Reference Guide


Guía de referencia
de piezas

Pièces Guide
de référence






Schematic Drawings Inside
Plano esquemático en el interior
Schéma intérieur







Repair Kits
YK0838
YK0839



Tool #	Model
9Y0001N	Contact-Actuation
9Y2001N	Contact-Actuation




A	
EA0393	Standard Piston Drive Assembly
EA0399	5/32" Longer Piston Drive Assembly



Contents Of YK0838 Repair Kit
Contents Of YK0839 Repair Kit

Construction Stapler

NS20BXP



REPLACEMENT PARTS LIST • LISTA DE PARTES DE REPUESTO • LISTE DE PIÈCES DE RECHANGE

PART NO.	DESCRIPTION	DESCRIPCIÓN	DÉSIGNATION
AB0227	COVER, EXHAUST	CUBIERTA	COUVERCLE
AB0228	CAP	TAPA	BOUCHON
AC0461	BELT HOOK	GANCHO DE CINTURÓN	CROCHET DE CEINTURE
AC0462	WASHER	ARANDELA	RONDELLE
AC0465	END CAP	TAPA TERMINAL	BOUCHON D'EXTRÉMITÉ DE RAIL
AC0546	GASKET	SEAL	JOINT
BC0867	SPRING	RESORTE	RESSORT
BC0868	VALVE, FIRING	VÁLVULA	VALVE
BC0869	SEAL, FIRING VALVE	SELLO, VÁLVULA QUE ENCIENDE	VALVE
BC0870	VALVE, EXHAUST	VÁLVULA	VALVE
BC0871	STOP	TOPPE	ARRÊT
BC0872	WASHER	ARANDELA	RONDELLE
BC0873	SEAL	SELLO	JOINT
BC0874	CYLINDER SLEEVE	CILINDRO	CYLINDRE
BC0875	PLATE	PLACA	PLAQUE
BC0935	DRIVER SEAL PLATE	PLACA DEL SELLO DEL PROGRAMA PILOTO	PLAT DE JOINT DE GESTIONNAIRE
BC0950	STOP	TOPPE	ARRÊT
EA0393	PISTON / DRIVER ASY	PERCUSOR	COUTEAU
EA0399	PISTON / DRIVER ASY	PERCUSOR	COUTEAU
FA0359	LATCH ASY	MONTAJE DEL CIERRE	ASY DE VERROU
FC1003	PLATE	PLACA	PLAQUE
FC1004	BACK PLATE	PLACA	PLAQUE
FC1005	FRONT PLATE	PLACA	PLAQUE
FC1006	PLATE	PLACA	PLAQUE
GA0751	SPRING ROLLER	RODILLO	GALET
GB0613(US)	MAGAZINE COVER (US)	CUBIERTA	COUVERCLE
GB0614(EU)	MAGAZINE COVER (CE)	CUBIERTA	COUVERCLE
GC1501	GRIP	AGARRADERO	GAINÉ EN CUIR
GC1673	BRACKET, MAGAZINE	SOPORTE	SUPPORT DE FIXATION
GC1674	DETAINER	RETENEDOR	ARRÊT
GC1675	FEDER	ALIMENTADOR	POUSSOIR
GC1677	MAGAZINE ASY	ASAMBLE DE CARGADOR	MAGASIN D'ASSEMBLÉE
GC1686	SPACER	ESPACIADOR	ENTRETOISE
GC1767	PIN	PASADOR	GOUPILLE
HA0321	TRIGGER ASSY (contact-actuation)	ASAMBLE DE GATILLO	ENSEMBLE GÂCHETTE
HA0322	TRIGGER ASSY (restrictive)	ASAMBLE DE GATILLO	ENSEMBLE GÂCHETTE
HC0418	COVER	CUBIERTA	COUVERCLE
HC0784	GUIDE, SAFETY	GUÍA	GUIDE
HC0785	SAFETY ELEMENT	SEGURO	PALPEUR DE SÉCURITÉ
HC0788	SIDING ATTACHMENT	CONEXIÓN DEL APARTADERO	CONNEXION DE VOIE DE GARAGE
KB6601	PIN	PASADOR	GOUPILLE
KB6666	SCREW M5*8	TORNILLO	VIS
KB6667	SCREW M5*18	TORNILLO	VIS
KB6669	SCREW M5	TORNILLO	VIS
KB6672	NUT	TUERCA	ÉCROU
KB6676	SNAP RING	ANILLO DE RETENCIÓN	ANNEAU RESSORT
KB7033	SCREW	TORNILLO	VIS
KB7039	SCREW M5*28	TORNILLO	VIS
KB9843	PIN	PASADOR	GOUPILLE
KB9855	SCREW	TORNILLO	VIS
KB9859	SCREW	TORNILLO	VIS
KB9861	SCREW	TORNILLO	VIS
KB9909	WASHER 14*1T	ARANDELA	RONDELLE
KD0233EU	SPRING	RESORTE	RESSORT
KD0236EU	SPRING	RESORTE	RESSORT
KD0237	PIN	PASADOR	GOUPILLE
KD0238	PIN	PASADOR	GOUPILLE
KD0249	PIN	PASADOR	GOUPILLE
LB1303	O-RING 24.5*3	SELLO	JOINT
LB1304	O-RING	SELLO	JOINT
LB1305	O-RING	SELLO	JOINT
LB1306	O-RING	SELLO	JOINT
LB1308	O-RING	SELLO	JOINT
LB1309	O-RING	SELLO	JOINT
LB1310	O-RING	SELLO	JOINT
LB5104	O-RING	SELLO	JOINT